

EECS16A Imaging 3



- Zoom has a new update!
- Buffer labs will be **10/6-10/9**
 - You can make up **one** missed lab from the Imaging Module, if needed (unless you have received approval to make-up multiple labs)
 - Fill out the sign-up form (linked at the end of the lab notebook) if you plan to attend a buffer section
 - See Buffer Logistics Piazza post for more details

Last time: Matrix-vector multiplication

1	0	0	0	0	0	0	0	...
0	1	0	0	0	0	0	0	...
0	0	1	0	0	0	0	0	...
0	0	0	1	0	0	0	0	...
0	0	0	0	1	0	0	0	...
0	0	0	0	0	1	0	0	...
0	0	0	0	0	0	1	0	...
...								

Masking Matrix H


i_1
i_2
i_3
i_n

Unknown,
vectorized
image, \vec{i}


=

s_1
s_2
s_3
s_n

Recorded
Sensor
readings, \vec{s}




Last time: Single-pixel scanning



- Setup a masking matrix where each row is a mask
 - Measured each pixel individually once

$$\vec{s} = H\vec{i}$$

- How did we reconstruct our image, once we had \vec{s} ?




- A. H is invertible.
- B. H has linearly independent columns
- C. Inverse of H must be unique.
- D. H has a trivial nullspace.
- E. Determinant of H is 0.

1. A, B, C
2. A, B, D, E
3. A, B, E
4. A, B, C, D, E


$$\vec{s} = H\vec{l}$$

Our system

Today: Multi-pixel scanning



- **Can we measure multiple pixels at a time?**
 - Measurements are now linear combinations of pixels
- **How can we reconstruct our scanned image?**
 - Is multi-pixel mask still possible to be linearly independent, aka invertible?



Why do we care?


- Improve image quality by averaging
 - Good measurements → good average
- Redundancy is useful
 - Averaging measurements is better than using bad measurement values
 - Does not “solve” bad measurements, but makes us tolerant of some errors



How do we do it?

- Change masks to illuminate multiple pixels per scan
 - Multiple 1's in each row of masking matrix H
 - Measure linear combinations of pixels instead of single pixels
- BUT multiple pixels \rightarrow more noise
 - Noise = random variation in our measurement that we don't want (ex: room light getting into box)
 - Signal = data that we do want (light from pixel illumination)
- Too much noise \rightarrow hard to distinguish signal from noise
 - Want high signal, low noise
 - High signal-to-noise ratio (SNR)

Mask 0: 272.0 Illuminated Pixels



What is Noise?

0.4
0.95
2.1
.
.
.
9.8

\vec{s}_{real}

Measured values =
ideal vector + noise vector (ω)

=


0
1
2
.
.
.
10

\vec{s}_{ideal}

+

0.4
-0.05
0.1
.
.
.
-0.2

$\vec{\omega}$





How does noise affect our system?

1	0	0	0	0	0	0	0	...
0	1	0	0	0	0	0	0	...
0	0	1	0	0	0	0	0	...
0	0	0	1	0	0	0	0	...
0	0	0	0	1	0	0	0	...
0	0	0	0	0	1	0	0	...
0	0	0	0	0	0	1	0	...
...								

Masking Matrix H

i_1
i_2
i_3
i_n

Unknown,
vectorized
image, \vec{i}

+

w_1
w_2
w_3
w_n

**Random
noise
vector, \vec{w}**

=

s_1
s_2
s_3
s_n

Recorded
Sensor
readings, \vec{s}

A more realistic system

- Sensor readings =
image vectors applied to H + noise vector

$$\vec{s} = H\vec{i} + \vec{w}$$

- We can't reconstruct \vec{i} , but we can estimate it

$$\vec{i}_{est} = H^{-1}\vec{s} = \vec{i} + \boxed{H^{-1}\vec{w}}$$

Be careful about the noise term or else it could blow up !!



Eigenvalues for inverse matrices

- H Is an NxN matrix that we know is linearly independent (invertible).
 - No eigenvalue = 0
- Assume H has N linearly independent eigenvectors
- $Hv_i = \lambda_i v_i$ for $i = 1 \dots N$
- N lin. ind. vectors can span \mathbb{R}^N
 - They span the noise vector

- The inverse of H has eigenvalues
(as proven in homework)

$$H^{-1}v_i = \frac{1}{\lambda_i}v_i \text{ for } i = 1 \dots N$$

$$\frac{1}{\lambda_1} \dots \frac{1}{\lambda_N}$$




$$\vec{l}_{est} = H^{-1}\vec{S} + H^{-1}\vec{\omega}$$


$$\boxed{H^{-1}\vec{\omega}} = \frac{1}{\lambda_1} \alpha_1 \vec{v}_1 + \frac{1}{\lambda_2} \alpha_2 \vec{v}_2 + \dots \frac{1}{\lambda_n} \alpha_n \vec{v}_n$$

- Remember: want small noise term for high signal-to-noise ratio
- The noise is directly related to the eigenvalues.

Poll Time!


- Do we want small or large eigenvalues for the H matrix in order to get a good image?
 1. Large
 2. The magnitude doesn't matter
 3. Small






Possible Scanning Matrix: Random


Mask 0: 272.0 Illuminated Pixels




Mask 1: 281.0 Illuminated Pixels



Mask 2: 313.0 Illuminated Pixels



Mask 3: 289.0 Illuminated Pixels




- Illuminate ~300 pixels per scan
 - Usually invertible
 - But what are its eigenvalues?

(ツ)



A more systematic scanning matrix:

- Hadamard matrix!
- Constructed to have large eigenvalues
 - Just what we need!



Using the Software Simulator

1. Start display view in another browser tab
2. Enter the imagePath and run the simulator + shift to display tab
3. Observe masks being projected onto the image + return to notebook tab
4. Observe generated sensor reading
5. Reconstruct image by multiplying with H inverse

Repeat steps 2-5 for each imaging experiment

Pointers

1. READ CAREFULLY - Long lab with lots of reading; heavily tests understanding of eigen-stuff (important for the exam)
 2. You see the noisy sensor reading generated at the end instead of being generated entry by entry (i.e. just one masking simulation visual per experiment, no more cumulative simulation)
 3. Choose an image that focuses on a single object and is not too detailed
 4. Use a simple imagePath name
 5. Before starting the imaging experiments, launch the display view in a separate tab using the link in the notebook
 6. Enter imagePath correctly for each simulation block
 7. Shift to the display tab as soon as you run a simulation block and return to the notebook once the visual has finished executing
- P.S. The masking simulation visual can be super trippy ;)

